


Supermarché Bamboo Box

Frame Mounted Front Box



yuba®
what a bicycle can do!

Supermarché Bamboo Box

Frame Mounted Front Box




Contents

- (1) Front Board
- (2) Side Boards
- (1) Back Boards
- (12) M5 Washers
- (12) M5 Bolts

Compatibility

Supermarché


Note: Installed Base Board required for assembly (purchase separately)



Instructions


1. Cut adhesive backed felt into eighteen 3.5 by 1.25 cm (1.375 by .6 in.) rectangles

Figure 1.




- 2. Remove paper backing from adhesive backed felt squares. Place on Side Boards between the indexing pegs, as shown in Figure 2.

Figure 2.




3. Place Front and Back Boards into their respective positions on the frame. Hold Front Board approximately 15 cm (6 in) above the Base Board, as shown below in Figure 3.

Figure 3.




4. While holding the Front Board elevated, individually insert the Side Boards first into the indexing slots in the Back Board, then into the slots in the Front Board, as seen in Figure 4.

Figure 4.




4. With both Side Boards indexed into the Front and Back Board, lower the Front Board so the Side Boards index into the Base Board. Lifting the Back Board vertically two to three inches while lowering the Front Board into place will help with installation.

Figure 4.




5. Insert screws, with washers, through the slots in the in the Back and Front Boards and into the frame, as seen in Figure 5. Tighten to 2 N-m, taking care not to over tighten and damage the bamboo.

Figure 5.



6. Thread bungee cords as seen in Figure 6, and knot on the inside of the Side Boards where circled below.

Figure 6.



Supermarché Bamboo Box

Frame Mounted Front Box



Warnings and Safety Precautions

General warnings

- **WARNING!** Failure to comply with these instructions may lead to serious injury or death.
- **WARNING!** Riding with an additional passenger may alter the riding characteristics of your bicycle, decrease stability, and increase braking distances.
- **WARNING!** Never leave a child unattended on the back of a bicycle.
- **WARNING!** Do not use with children who are too small or cannot balance/support their own weight independently.
- Do not allow passengers body, clothing, shoe laces or other personal items to come in contact with moving parts of the bicycle.
- Passenger should remain seated while bicycle is in motion.
- Ensure passenger is wearing an approved bicycle helmet.
- Never ride in inclement or hazardous situations.
- Ensure a rear reflector is installed and visible when a passenger is aboard.
- Never ride a bicycle at night without adequate lighting.
- Presence of an additional passenger may require alteration of the method used by the rider to mount or dismount the bicycle. Care must be taken whenever the rider gets on or off the bicycle.

Specific hardware and component warnings

- **WARNING!** Overloading bolts may cause it to fail.
- **WARNING!** Regularly check bolts for loosening, signs of distress, and wear and tear. If bolts or threads show signs of distress, order replacement parts immediately. Do not use if parts are cracked or damaged.
- **WARNING!** Regularly check bamboo panels for cracks or dents, and replace if damaged.

For questions or support please contact your local Yuba Bicycles dealer or email info@yubabikes.com.

