



Installing the Pop-Top on Mini Monkey Bars




Step 1: Assemble Pop-Top and set to "Long Setup" as per assembly instructions.



Step 2: Position PT clamps in front of the forward cross bar and behind the rear cross bar respectively.



Step 3: Attach Clamps. Ensure that the clamps are tight enough that they won't slide around, but not so tight that they can't be opened again



Step 4: Wrap velcro straps around the clamps



Step 5: Ensure that the access flap zipper closes completely

